


WiMAC Bootcamp: Week 1

WiMAC Team

Warm-Up: LabVIEW Communication Examples



Please go through
"Programming Basics"
before you start LV
Host programming

Programming Basics

LEARN | EXAMPLES

<

<h3>Designing a User...</h3> <p>This lesson illustrates how to design a user interface, or UI, for a program.</p>	<h3>Controlling the...</h3> <p>Learn how to use diagram components to define what happens to your data while your VI runs.</p>	<h3>Storing and...</h3> <p>This lesson demonstrates how to capture, store, view, and analyze data.</p>
<h3>Debugging Your...</h3> <p>Learn where to find and how to use debugging tools to troubleshoot your code.</p>	<h3>Identifying and...</h3> <p>Learn how to create code that is scalable and reusable.</p>	<h3>Basic Data Types</h3> <p>This lesson illustrates the basic data types available in graphical programming.</p>
<h3>Arrays</h3> <p>This lesson illustrates how to create and manipulate arrays.</p>	<h3>Clusters</h3> <p>This lesson teaches you how to create and manipulate clusters.</p>	<h3>While Loops</h3> <p>This lesson teaches you how to use a While Loop to repeat code until a</p>

TODOs and Timeline

Part 1: Hook up LV Host and VLC player: 2 week  We are here

Part 2: Implement basic scheduling in FPGA: 3 weeks

Part 3: Implement our smart policy: 4 weeks

Part 4: Verification and more advanced topics: 3 weeks


Part 5: Produce a demo video: 2 weeks

Let's target "Dec 15, 2017" for this mini-project!


Task 1: Stream 1 Video to 1 UDP Sink

Task 1: Stream 1 Video to 1 UDP Sink

VLC (Source)




VLC (Sink)



- Use vanilla version
- Use RF Loopback (MAC source address = MAC destination address)

LabVIEW Host




LabVIEW FPGA


Task 1 Highlights: Stream 1 Video to 1 UDP Sink

- Use the vanilla version which supports 1 UDP source
- All you need to do is change the front panel settings
 - UDP source and UDP sink
- See the following 3 pages about how to hook up LV Host and VLC player
- Note: You can run the LV code using 1 USRP RIO with RF loopback

802.11 Application Framework: Vanilla Version






Hint: Hook Up RX and VLC Player: LabVIEW Host



- You can choose any UDP port you like (as long as it is not used by other applications)
- IP address can be found by using "ipconfig" at the Terminal


Hint: Hook Up RX and VLC Player: Source

- UDP source: VLC application
 - Media -> Stream, then “Add” a video file and press “Stream”
 - Select “RTP/MPEG Transport Stream” and check “Display locally”, then press Add
 - Type in the IP address and UDP port # of the Host machine



Hint: Hook Up RX and VLC Player: Sink

- UDP sink: VLC application
 - Media -> Open Network Stream, then enter the network URL (e.g. `rtp://@:4444`, 4444 is the port # of UDP sink)
 - Then, click “Play”



Task 2: Stream 5 Videos to 1 UDP Sink

Task 2: Streaming Multiple Videos on WiMAC


VLC1



VLC2



VLC1



VLC2



LabVIEW Host



LabVIEW FPGA



LabVIEW Host




LabVIEW FPGA

Task 2 Highlights: Stream 5 Videos to 1 UDP Sink


- Extend the [vanilla version](#) so that it supports 5 UDP sources
- All you need to do is change [Host code](#)
 - Task 2(a): Create 5 [Host queues](#) (See “802.11 Host Init”)
 - Task 2(b): Create 5 [UDP sources](#) (See “802.11 Configure Data Source” and “802.11 Receive UDP Data”)
 - Task 2(c): Push data from 5 UDP sources to 5 Host queues
 - Task 2(d): Create a [manual video scheduler](#) (a new module) so that you can choose 1 out of 5 video streams anytime
- How to test? Manually schedule 1 video stream using a front panel control

Top-Level VI (802.11 Host.gvi)



Task 2(a): Host Queues


- Create a queue by using “Obtain Queue”



- “Enqueue” and “Dequeue” and more


Task 2(a): How to Create 5 Host Queues?

- 802.11 Host Init.gvi
- In vanilla version, only 1 “send queue”





Session: “Cluster” & “Type Definition”

- Cluster = a group of elements
 - Possibly different data types
- Type = similar to “struct” in C language
 - “Type” can be created from cluster
 - A cluster can be connected/not connected to a type




Type definition




Item		Document	
Name	Cluster Constant		
Type	Cluster Constant		
▼ Data Items			
TF	0	True Constant	
132	1	Numeric Constant	
1081	2	Array Constant	
▼ Visual Style			
Label			
<input checked="" type="checkbox"/> Show Label			
Label Placement		Label on Top ▼	
<input checked="" type="checkbox"/> Autosize Label			
▼ Layout			
Arrange		None ▼	
▼ Documentation			
Context Help		Online Help	
▼ Type Definition			
Change to Type Definition			

Task 2(b): UDP Source

- See “802.11 Configure Data Source.gvi”
- Follow the same approach and create 4 more UDP receiver




Hint: Configure 5 UDP Sources




Task 2(c): Push Data from UDP to Host Queues

- While loop for UDP send and receive
 - Please see 802.11 Receive UDP Data.gvi




Hint: Push UDP Data to 5 Host Queues

- Create a new module “802.11 Receive UDP Data 5 Streams.gvi”
- Follow the same approach as the original “802.11 Receive UDP Data.gvi”, but with 5 UDP sources and 5 Host queues




Task 2(d): Manual Scheduler

- In the While loop for TX Transmission
 - Create a new module “Manual Scheduler”



Hint: Manual Scheduler

- Create a new module “Manual Scheduler.gvi”
- Follow the same approach as the original “802.11Receive UDP Data.gvi”



Hint: Manual Scheduler

- Put the control “Stream selector” on the front panel

802

Overview

Demonstrates 802.11 Rx and Tx

Instructions

1. Cable device depending on operation mode selected.
2. Make sure "RIO Device" names the RIO alias of the de
3. Start the VI and enable the station.

Station

Operation Mode RF Loopback Off On

Basic **Advanced** **Events**

Transmit

TX Port (USRP only) Primary Subband TX1/RF 0 1

Device MAC Address 47 6F 48 75 6D 61

Data Source UDP Data Source Option UDP PN Data Manual

TX Data Dropped ☐

Stream selector Stream 1

MAC TX Statistic

TX after SIFS Requests Detected 0

TX after SIFS Requests Completed 0

TX after Backoff Requests Detected 0

TX after Backoff Requests Completed 0

Reset TX Statistic

Receive Port 0

RFC Full ☐

Data Transfer 0

Destination MAC Address 47 6F 48 75 6D 62

Overwritten by Device MAC Address ☒

Backoff 4

RF Input Power current

RF input power [dBm]

Time [%s]

Last But Not Least!

1. ALWAYS PUT COMMENTS in your code!!!
2. ALWAYS PUT COMMENTS in your code!!!
3. ALWAYS PUT COMMENTS in your code!!!
4. Take snapshots and write your own technical documents
5. Check in your code to GitHub (recommended)
6. Whenever you have a question, check the online manual first:
7. <http://www.ni.com/documentation/en/labview-comms/2.0/manual/labview-comms-manual/>
8. <http://www.ni.com/white-paper/53279/en/>